


Ersatzteile - Spare parts - Pièces de rechange - Reserveonderdelen - Parti di ricambio - Reservedele - Reservdelar
 Varaosat - Części zamienne - Náhradní díly - Alkatrészek - Piese de schimb - Запасные части - 备件



①	Klemmflansch	Clamping flange	JP46172
②	Wartungsdeckel	Service lid	JP46161
③	Überschiebmuffe	Collar	JP47287
④	Niveauschaltung	Level control	JP47306
⑤	Behälterfuß	Container foot	JP46170
⑥	Bodenbefestigung	Fixation	JP46171
⑦	Stopfen	Plug	JP46165
⑧	Elast. Verbindung	Elastic connector	JP43705
⑨	Pumpenlüftung	Pump ventilation	JP46169
⑩	Pumpe	Pump	
	15/4 BW1		JP09455
	25/4 BW1		JP09456
	35/4 BW1		JP09457
	25/2 BW1		JP09498
	35/2 BW1		JP09500
	15/4 CW1		JP09612
	25/4 CW1		JP09655
	35/4 CW1		JP09858
⑪	Pumpenbefestigung	Pump retainer	JP46168
⑫	Flanschanschluss	Flanged outlet	
	DN 80 (BW1)		JP00578
	DN 100 (CW1)		JP00579
⑬	Einflanschstück	Spigot flange	JP08673

43143-04