



BASICLOGO AD ... XM / BASICLOGO AD ... EXM, TLS

Ersatzteile - Spare parts - Pièces de rechange - Reserveonderdelen - Parti di ricambio - Reservedele - Reservdelar
 Varaosat - Części zamienne - Náhradní díly - Alkatrészek - Piese de schimb - Запасные части - 备件



| | | | |
|---|-----------------------|-------------------------|----------------|
| ① | Gehäuse ADP | Housing ADP | JP47692 |
| ② | Scharnier | Hinge | JP48310 |
| ③ | Wippschalter | Switch, 3 positions | JP47783 |
| ④ | Taster | Button | JP48309 |
| ⑤ | Klemme RK 2,5-4 | Terminal RK 2,5-4 | JP48308 |
| ⑥ | Betriebsstundenzähler | Operation hours counter | JP47672 |
| ⑦ | Gedruckte Schaltung | PCB | |
| | AD 25 ExM | | JP47706 |
| | AD 46 ExM | | JP47707 |
| | AD 610 ExM | | JP47709 |
| ⑧ | Überstromrelais | Overcurrent relay | |
| | ZE-4 2,4-4 A | | JP47779 |
| | ZE-6 4-6 A | | JP47780 |
| | ZE-9 6-9 A | | JP47781 |
| ⑨ | Schütz DIL EM 10 | Contactor DIL EM 10 | JP47671 |



| | Niveaugeber | Level detector | |
|---|----------------------------|---------------------------|----------------|
| ⑩ | Druckschalter 100/50 | Pressure switch | JP47699 |
| ⑪ | Sicherheitsbarriere | Safety barrier ATEX | JP46348 |
| ⑫ | TLS Halter | | JP46456 |
| ⑬ | TLS Tauchschalter 9,5m | | JP48304 |
| | TLS Tauchschalter 15 m | | JP48873 |
| | TLS Tauchschalter 20 m | | JP47771 |
| | TLS Tauchschalter 30 m | | JP47772 |
| ⑭ | 2x Schlauchbefestigung | 2x Hose fastening | JP48141 |
| ⑮ | 2x Verschraubung | 2x Hose connector | JP48142 |
| ⑯ | 2x Schlauch, 10m | 2x Hose, 10m | JP48143 |
| | 2x Schlauch, 15m | 2x Hose, 15m | JP48144 |
| | 2x Schlauch, 20m | 2x Hose, 20m | JP48145 |
| | 2x Schlauch, 30m | 2x Hose, 30m | JP48840 |
| ⑰ | Luftglockenset, 10m | Pressure sensor set, 10m | JP48148 |
| ⑱ | Luftglocke m Schlauch, 10m | Press. sensor w hose, 10m | JP47698 |
| ⑲ | 20x Fangflasche | 20x Catch hanger | JP46904 |